

R

Please add a new device

Home page appears. Press the "ADD DEVICE" button to add HT500 SET.







Press the "SELECT" button for HT500 SET.



Give the device a name and press "Continue" button.



If you activate the Location Mode, your Smart Room Thermostat will automatically bring the ambient temperature to the value you have set when you approach or move away from the relevant location.

#### **Location Access**

GLife collects location data to automatically adjust the ambient temperature according to value you have set as you approach or move away from the relevant location where your Smart Room Thermostat is located even when the application is closed or not in use.

#### OK

Location Permission is Obtaining...

Allow location access to use "Location Mode" and see current weather condition.



Firstly, remove the key lock while setting up your HT500 SET device. Press the On/Off button for 4 seconds to switch the device to Off mode. Then, press the temperature decrease button for 4 seconds and wait for '1' appears on the screen.

'1' Appeared on the Screen

Plug in the device before initiating the setup. Remove the key lock by pressing the " Mode " button for 2 seconds.

Turn off the device by pressing the "On/Off " button for 4 seconds.

The number "1" will appear on the screen once you press the temperature decreasing button for 4 seconds.



# Connect to HT500SET\_XXXX network with Wi-Fi and proceed to the next screen

#### Check the HT500 SET connection

Go to the Wi-Fi settings of your device and make sure you are connected to the HT500SET\_XXXX network. Then, press the "Check the HT500 SET connection" button.



Choose the Wi-Fi Network you use at your home or office and enter the password

ISIPARK	-
ISIPARK-GUEST	$\overline{\mathbf{v}}$
ISIPARK-1	$\mathbf{\overline{v}}$
ISIPARK-2	$\mathbf{\overline{v}}$
HP-PRINT	$\bigtriangledown$
ISIPARK	
generallife	

Connect to Wi-Fi

Choose the Wi-Fi Network that HT500 SET can connect and enter the password. In case the Wi-Fi network does not appear in the list, manually type the network name

Press "Connect to Wi-Fi" button once correct information is entered.



Please wait until '2' and '3' appears on HT500 SET's screen, respectively. If '1' appeared on the screen, it indicates that you have entered incorrect Wi-Fi information. Please turn back to HT500 SET network connection step and follow the instructions again.

'3' Appeared on the Screen

Wait until the number "3" is shown on the device. Press the button if you see the number "3" on the device.

\*If the number "1" is shown on the device, it means you have entered incorrect Wi-Fi information. Enter the correct information by returning back to the "Connect to Wi-Fi" step.





While pairing the Room Thermostat with the Receiver, you must press the pairing button on the Receiver and wait for green light flashing. Subsequently, press the temperature increase button for 4 seconds. The Receiver will beep and the LED will turn constant green. The Room thermostat and the Receiver are paired now. You will see the main screen of HT500 SET.



While pairing HT500 SET follow below steps respectively ;

- Press the pairing button on the Receiver and wait until LED blinks green.
- Then, press the temperature increase button of HT500 SET for 4 seconds.
- LED on the Receiver will be steady and HT500 SET main screen will appear.
- If you have completed the steps, press the "Pairing completed" button.





# Go to Wi-Fi settings, leave the device's network and connect a network with internet connection

I reconnected to Wi-Fi Network

Connect to your home Wi-Fi Network by opening your phone's Wi-Fi settings and press the "I reconnected to Wi-Fi Network" button. You will be redirected to the home page.



You can see your application membership information and log out of the application.







### ACCOUNT INFORMATION

**Contact Informations** 

ht500set@generallife.com.tr

Log out

Build v1.0.9.0

If you would like to log out of the application, you may press the "Log Out" button.



Devices linked to your account shown here.

Shuts down HT500 SET and heating unit.

▲ Button increases the set temperature value and the heating unit is controlled according to this value.

► Button reduces the set temperature value and the heating unit is controlled according to this value.

Select the device you wish to control.





Main menu of HT500 SET appears and device name shown here.



The heating unit is managed according to the temperature set for home mode.



The heating unit is managed according to the temperature set for away mode.



The heating unit is managed according to the temperature set for sleep mode.



The heating unit is managed according to the temperature in the schedule added on a day and 30 minute basis in the Program Mode.



The screen where you can set the daily or weekly schedule settings appears when you press on the "Add/Delete Schedule" button.

You can access the same menu by pressing the Program Mode button for 3 seconds.

## ISIPARK

#### **PROGRAMMING MODE**

#### Monday

000102030405060708091011121314151617181920212223

#### **Tuesday**

000102030405060708091011121314151617181920212223

#### Wednesday

000102030405060708091011121314151617181920212223

#### Thursday

000102030405060708091011121314151617181920212223

**Friday** 

ADD SCHEDULE

+

A daily or weekly schedule is added by pressing the "ADD SCHEDULE" button.



Select the day or days you wish to program.

Select the time you wish to program.

/ button sets the desired temperature to program.

The changed settings are saved by pressing "SAVE THE SCHEDULE" button.



If you wish to change or delete the setting made; Press on the time you wish to change or delete. "Edit" or "Delete" buttons located in the upper right corner can be used to make changes.

# **ISIPARK PROGRAMMING MODE** 22 000102030405060708091011121314151617181920212223 **Friday** 000102030405060708091011121314151617181920212223 Saturday 000102030405060708091011121314151617181920212223 Sunday 000102030405060708091011121314151617181920212223



Remove all schedules

Pressing "Remove all schedules" button opens the page to remove all schedules added.



All schedules are removed when pressed "Yes" button.



## **ISIPARK**

#### **PROGRAMMING MODE**

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### **Friday**

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### Saturday

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### Sunday

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

Remove all schedules

All schedules have been removed

You can return to the previous menu by pressing the "Back" button.



The heating unit is managed according to the range and temperature set for home mode.



Press the "Location Mode" button for 3 seconds to quickly switch to the "Location Mode" settings.

The screen where you can set the location mode settings will appear.



Desired range and temperature value for the "Location Mode" can be set here.



Desired range and temperature value for the "Location Mode" can be set here.



Press the "Save the Changes" button to save the changes have been made.



Temperature value measured by HT500 SET is shown here.



Set temperature value for the selected mode is shown here.



• button reduces the set temperature value and the heating unit is managed according to this value.

• button increases the set temperature value and the heating unit is managed according to this value.

Manuel Mode becomes active.



Shows the internet connection status of HT500 SET.



#### Shows the location of HT500 SET.



Estimated outside temperature taken from the meteorological data station according to the position of the HT500 SET is shown here.


Settings menu can be opened by pressing here.



The backlight of the HT500 SET is turned on or off by pressing here.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
<b>\$</b>	Calibration Settings	1.0°
0	Turn off the Device	
i	Device Informations	>
ľ	Modes	>
ጽ	Device Users	>
\$	Resync the Device	>

Device calibration setting can be done here.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
¢	Calibration Settings	0.0°
0	Turn on the Device	
i	Device Informations	>
	Modes	>
ନ୍ଧ	Device Users	>
¢	Resync the Device	>

Shuts down HT500 SET and heating unit.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
<b>(</b>	Calibration Settings	0.0°
0	Turn off the Device	
i	Device Informations	>
	Modes	>
ጽ	Device Users	>
\$	Resync the Device	>

Device name can be changed here.



Changed device name can be saved by pressing "Save the Device Name" button.



You can return to the previous menu by pressing the "Back" button.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
<b>\$</b>	Calibration Settings	0.0°
0	Turn off the Device	
i	Device Informations	>
Ō	Modes	>
ନ୍ଧ	Device Users	>
\$	Resync the Device	>

The screen which temperature values of the modes can be set appears.

<	ISIPARK	
	MODES	
	Home Mode	
	<b>24.0</b> °	<b>~</b>
	Away Mode	
€	<b>18.0</b> °	<b>^</b>
	Sleep Mode	
	<b>20.0</b> °	$\hat{\mathbf{v}}$
	Programming Mode	>
0	Location Mode	>
	Ct RESET THE MODES	

Temperature values of the Home, Away and Sleep Modes can be set.

<	ISIPARK	
	MODES	
	Home Mode	
	<b>24.0</b> °	<b>~</b>
	Away Mode	
€	<b>18.0</b> °	<b>~</b>
	Sleep Mode	
	<b>20.0</b> °	<b>~</b>
	Programming Mode	>
0	Location Mode	>
	Cr RESET THE MODES	

Program Mode appears to add/delete daily or weekly schedule.

## ISIPARK

#### **PROGRAMMING MODE**

#### Monday

000102030405060708091011121314151617181920212223

#### **Tuesday**

000102030405060708091011121314151617181920212223

#### Wednesday

000102030405060708091011121314151617181920212223

#### Thursday

000102030405060708091011121314151617181920212223

**Friday** 

ADD SCHEDULE

+

A daily or weekly schedule is added by pressing the "ADD SCHEDULE" button.



Select the day or days you wish to program.

Select the time you wish to program.

/ button sets the desired temperature to program.

The changed settings are saved by pressing "SAVE THE SCHEDULE" button.



If you wish to change or delete the setting made; Press on the time you wish to change or delete. "Edit" or "Delete" buttons located in the upper right corner can be used to make changes.

# **ISIPARK PROGRAMMING MODE** 22 000102030405060708091011121314151617181920212223 **Friday** 000102030405060708091011121314151617181920212223 Saturday 000102030405060708091011121314151617181920212223 Sunday 000102030405060708091011121314151617181920212223



Remove all schedules

Pressing "Remove all schedules" button opens the page to remove all schedules added.



All schedules are removed when pressed "Yes" button.



## **ISIPARK**

#### **PROGRAMMING MODE**

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### **Friday**

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### Saturday

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

#### Sunday

 $00{\scriptstyle 01} 02{\scriptstyle 03} 04{\scriptstyle 05} 06{\scriptstyle 07} 08{\scriptstyle 09} 10{\scriptstyle 11} 12{\scriptstyle 13} 14{\scriptstyle 15} 16{\scriptstyle 17} 18{\scriptstyle 19} 20{\scriptstyle 21} 22{\scriptstyle 23}$ 

Remove all schedules

All schedules have been removed

You can return to the previous menu by pressing the "Back" button.

<	ISIPARK	
	MODES	
	Home Mode	
	<b>24.0</b> °	<b>~</b>
	Away Mode	
€	<b>18.0</b> °	<b>~</b>
	Sleep Mode	
	<b>20.0</b> °	<b>~</b>
	Programming Mode	>
0	Location Mode	>
	CT RESET THE MODES	

The screen appears where you can set the location mode settings.



Desired range and temperature value for the Location Mode can be set here.



Desired range and temperature value for the Location Mode can be set here.



Press the "Save the Changes" button to save the changes have been made.

<	ISIPARK	
	Home Mode	
	<b>24.0</b> °	<b>~</b>
	Away Mode	
€	<b>18.0</b> °	<b>~</b>
	Sleep Mode	
C	<b>20.0</b> °	<b>~</b>
	Programming Mode	>
0	Location Mode	>
	RESET THE MODES	

Restores set values for all modes to factory settings.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
<b>\$</b>	Calibration Settings	0.0°
0	Turn off the Device	
i	Device Informations	>
Ū	Modes	>
ጽ	Device Users	>
¢	Resync the Device	>

The list of current users is shown here. User can be added or removed in this page.

## **ISIPARK**

#### **DEVICE USERS**

A ht500set@generallife.com.tr

<



Adds invited user to manage HT500 SET.



The e-mail address of the invited user must to be entered.





The invited user is deleted.

<	ISIPARK	
	DEVICE SETTINGS	
Q	Turn off the Device's Backlight	
<b>\$</b>	Calibration Settings	0.0°
$\odot$	Turn off the Device	
i	Device Informations	>
Ū	Modes	>
දි	Device Users	>
¢	Resync the Device	>

Resets HT500 SET.



If you activate the Location Mode, your Smart Room Thermostat will automatically bring the ambient temperature to the value you have set when you approach or move away from the relevant location.

#### **Location Access**

GLife collects location data to automatically adjust the ambient temperature according to value you have set as you approach or move away from the relevant location where your Smart Room Thermostat is located even when the application is closed or not in use.

#### OK

Location Permission is Obtaining...

Allow location access to use "Location Mode" and see current weather condition.



Firstly, remove the key lock while setting up your HT500 SET device. Press the On/Off button for 4 seconds to switch the device to Off mode. Then, press the temperature decrease button for 4 seconds and wait for '1' appears on the screen.

'1' Appeared on the Screen

Plug in the device before initiating the re-pairing process. Remove the key lock by pressing the " Mode " button for 2 seconds.

Turn off the device by pressing the "On/Off " button for 4 seconds.

The number "1" will appear on the screen once you press the temperature decreasing button for 4 seconds.



# Connect to HT500SET\_XXXX network with Wi-Fi and proceed to the next screen

#### Check the HT500 SET connection

Go to the Wi-Fi settings of your device and make sure you are connected to the HT500SET\_XXXX network. Then, press the "Check the HT500 SET connection" button.



Choose the Wi-Fi Network you use at your home or office and enter the password

ISIPARK	-
ISIPARK-GUEST	$\overline{\mathbf{v}}$
ISIPARK-1	$\mathbf{\overline{v}}$
ISIPARK-2	$\mathbf{\overline{v}}$
HP-PRINT	$\bigtriangledown$
ISIPARK	
generallife	

Connect to Wi-Fi

Choose the Wi-Fi Network that HT500 SET can connect and enter the password. In case the Wi-Fi network does not appear in the list, manually type the network name

Press "Connect to Wi-Fi" button once correct information is entered.



Please wait until '2' and '3' appears on HT500 SET's screen, respectively. If '1' appeared on the screen, it indicates that you have entered incorrect Wi-Fi information. Please turn back to HT500 SET network connection step and follow the instructions again.

'3' Appeared on the Screen

Wait until the number "3" is shown on the device. Press the button if you see the number "3" on the device.

\*If the number "1" is shown on the device, it means you have entered incorrect Wi-Fi information. Enter the correct information by returning back to the "Connect to Wi-Fi" step.





While pairing the Room Thermostat with the Receiver, you must press the pairing button on the Receiver and wait for green light flashing. Subsequently, press the temperature increase button for 4 seconds. The Receiver will beep and the LED will turn constant green. The Room thermostat and the Receiver are paired now. You will see the main screen of HT500 SET.



While pairing HT500 SET follow below steps respectively ;

- Press the pairing button on the Receiver and wait until LED blinks green.
- Then, press the temperature increase button of HT500 SET for 4 seconds.
- LED on the Receiver will be steady and HT500 SET main screen will appear.
- If you have completed the steps, press the "Pairing completed" button.





# Go to Wi-Fi settings, leave the device's network and connect a network with internet connection

I reconnected to Wi-Fi Network

Connect to your home Wi-Fi Network by opening your phone's Wi-Fi settings and press the "I reconnected to Wi-Fi Network" button. You will be redirected to the home page.



In case you forget your password, press the "LOGIN" button on the initial screen.



Press the "Forgot Password" button in the LOGIN screen.



Enter the e-mail address linked to your account and press "Send" button.



- On the page that appears, 2 codes need to be entered.
- Codes can be found in the emails under the HT400 and GLife subjects sent to your email address which you entered for the password reset request.
- Enter the codes to the "Code1" and "Code2" sections in the application regardless their order.



Enter your new password to the "Password" and "Re-enter Password" sections in the page appears after you entered to codes and press "Update" button.



#### Step Into the World of GENERAL Life

C LOGIN C REGISTER C INVITED USER

Password successfully changed. Please login with your new password

Build v1.0.9.0

Once you see the "Password successfully changed." notification, you can use your new password.